


Advanced Tab

Administrator / System Setup / Advanced

This is where the global OnFinish Check Plugin DLL that is to be used across all stations is set. Use the [Browse] button to locate the DLL and then save changes.



To set the interface plugin on a per-station basis, use the Advanced tab in Station Setup.